

## 【VoLTE】 VoLTE



1.設定



2.行動服務



3.行動數據選項



4.語音與數據




5.VoLTE→開啟




6.完成

# Turn on/off VoLTE




1.Settings




2.Cellular




3.Cellular Data Options



4.Voice & Data



5.Turn on VoLTE



6.Finished