

## 【VoLTE】 Wi-Fi 通話(Wi-Fi Calling)

## 使用時須連線 Wi-Fi 網路



方式一：1.設定




2.行動服務



3.Wi-Fi 通話



4.在 iPhone 上進行 Wi-Fi 通話→開啟



5.啟用



6.完成



方式二：1.設定




2.電話



3.Wi-Fi 通話



4. 在 iPhone 上進行 Wi-Fi 通話 → 開啟



5. 啟用



6. 完成

### 搭配 eSIM 使用雙 SIM 卡開啟 Wi-Fi 通話



方式一：1. 設定



2. 行動服務




3. 選擇 SIM (例：主要-eSIM)



4. Wi-Fi 通話



5. 在 iPhone 上進行 Wi-Fi 通話 → 開啟



6. 啟用



7.完成




方式二：1.設定



2.電話



3.Wi-Fi 通話


4.選擇行動方案  
(例：主要-eSIM)5.在 iPhone 上進行  
Wi-Fi 通話→開啟

6.啟用




7.完成

# Activate Wi-Fi calling (Turn on Wi-Fi and connect to a Wi-Fi network)



## Method One:


### 1.Settings



### 2.Cellular




### 3.Wi-Fi Calling



### 4.Enable Wi-Fi Calling on This iPhone



### 5.Enable




### 6.Finished



## Method Two:


### 1.Settings




### 2.Phone




### 3.Wi-Fi Calling



4.Enable Wi-Fi Calling on This iPhone



5. Enable




6.Finished


Use dual SIM with an eSIM to activate Wi-Fi calling (Turn on Wi-Fi and connect to a Wi-Fi network)



Method One:  
1.Settings




2.Cellular




3.Select SIMs  
(e.g., Primary-eSIM)




4.Wi-Fi Calling





5.Enable Wi-Fi Calling on This iPhone




6. Enable




7.Finished

Method Two:  
1.Settings4.Select Cellular Plans  
(e.g., [Primary-eSIM](#))


2.Phone

5.Enable Wi-Fi Calling  
on This iPhone

3.Wi-Fi Calling



6.Enable



7.Finished

CHTT HSDDB