

【VoLTE】 Wi-Fi 通話(Wi-Fi Calling)

使用時須連線 Wi-Fi 網路



方式一：1.設定




2.行動服務



3.Wi-Fi 通話



4.在 iPhone 上進行 Wi-Fi 通話→開啟



5.啟用



6.完成



方式二：1.設定




2.電話



3.Wi-Fi 通話



4. 在 iPhone 上進行 Wi-Fi 通話 → 開啟



5. 啟用



6. 完成

搭配 eSIM 使用雙 SIM 卡開啟 Wi-Fi 通話



方式一：1. 設定



2. 行動服務




3. 選擇 SIM (例：主要-eSIM)



4. Wi-Fi 通話



5. 在 iPhone 上進行 Wi-Fi 通話 → 開啟



6. 啟用



7.完成




方式二：1.設定



2.電話



3.Wi-Fi 通話


4.選擇行動方案
(例：主要-eSIM)5.在 iPhone 上進行
Wi-Fi 通話→開啟

6.啟用




7.完成

Activate Wi-Fi calling (Turn on Wi-Fi and connect to a Wi-Fi network)



Method One:


1.Settings



2.Cellular




3.Wi-Fi Calling



4.Enable Wi-Fi Calling on This iPhone



5.Enable




6.Finished



Method Two:


1.Settings



2.Phone




3.Wi-Fi Calling



4. Enable Wi-Fi Calling on This iPhone




5. Enable





6. Finished


Use dual SIM with an eSIM to activate Wi-Fi calling (Turn on Wi-Fi and connect to a Wi-Fi network)

Method One:
1. Settings


2. Cellular

3. Select SIMs
(e.g., Primary-eSIM)


4. Wi-Fi Calling




5. Enable Wi-Fi Calling on This iPhone



6. Enable






7.Finished

Method Two:
1.Settings


2.Phone



3.Wi-Fi Calling

4.Select Cellular Plans
(e.g., [Primary-eSIM](#))5.Enable Wi-Fi Calling
on This iPhone

6.Enable



7.Finished

CHTT HSDDB