

【VoLTE】 Wi-Fi 通話(Wi-Fi Calling)

使用時須連線 Wi-Fi 網路



方式一：1.設定




2.行動服務



3.Wi-Fi 通話



4.在 iPhone 上進行 Wi-Fi 通話→開啟



5.啟用



6.完成



方式二：1.設定




2.電話



3.Wi-Fi 通話



4. 在 iPhone 上進行 Wi-Fi 通話 → 開啟



5. 啟用



6. 完成

搭配 eSIM 使用雙 SIM 卡開啟 Wi-Fi 通話



方式一：1. 設定



2. 行動服務




3. 選擇 SIM (例：eSIM)



4. Wi-Fi 通話



5. 在 iPhone 上進行 Wi-Fi 通話 → 開啟



6. 啟用



7.完成






方式二：1.設定




2.電話



3.Wi-Fi 通話


4.選擇 SIM
(例：eSIM)5.在 iPhone 上進行
Wi-Fi 通話→開啟

6.啟用




7.完成

Activate Wi-Fi calling (Turn on Wi-Fi and connect to a Wi-Fi network)




Method One:
1.Settings




2.Cellular



3.Wi-Fi Calling




4.Enable Wi-Fi Calling
on This iPhone




5.Enable




6.Finished




Method Two:
1.Settings




2.Phone




3.Wi-Fi Calling



4.Enable Wi-Fi Calling on This iPhone




5.Enable




6.Finished

Use dual SIM with an eSIM to activate Wi-Fi calling (Turn on Wi-Fi and connect to a Wi-Fi network)

Method One:
1.Settings


2.Cellular



3.Select SIMs (e.g., eSIM)




4.Wi-Fi Calling




5.Enable Wi-Fi Calling on This iPhone



6.Enable






7.Finished

Method Two:
1.Settings


2.Phone



3.Wi-Fi Calling

4.Select SIMs
(e.g., eSIM)5.Enable Wi-Fi Calling
on This iPhone

6.Enable



7.Finished